



**DIP SWITCH SETTING**  
(After changing the dip code,press "reset"or power-on again)

DIP	S/W	STATUS	FUNCTION
PIN 1	OFF/ON	NG / NG	
PIN 2	OFF/ON	NG / NG	
PIN 3	OFF/ON	Close front view camera/Open front view camera	
PIN 4	OFF/ON	Reversing gridline/Enable 360 panoramic	
PIN 5	OFF/ON	NG / NG	
PIN 6	OFF/ON	Rear view camera CVBS input / RGB input	
PIN 7	OFF/ON	NG / NG	
PIN 8	OFF/ON	Aftermarket rear view CAM/Original rear view CAM	



**REMARK:**Please keep in the AUX interface when switch the CarPlay interface

- 1) Long press and hold "MENU" button to switch MENU, long press"MENU" button again,exit the switch MENU.
- 2)Short press "SOUND" button to open "Siri".
- 3)Other functions use touch screen to control it.