



Audi (A4/Q5---LDS-A4) WIRING DIAGRAM



DIP SWITCH SETTING
(After changing the dip code, press "reset" or power-on again)

DIP	S/W	Status	Function
PIN 1	OFF/ON		Without touch panel/with touch panel
PIN 2	OFF/ON		NG/Touch point coordinate correction, and PIN1"ON"
PIN 3	OFF/ON		Close front view camera/Open front view camera
PIN 4	OFF/ON		Reversing gridline/Enable 360 panoramic
PIN 5	OFF/ON		NG / NG
PIN 6	OFF/ON		Rear view camera CVBS input / RGB input
PIN 7	OFF/ON		NG / NG
PIN 8	OFF/ON		Aftermarket rear view CAM/Original rear view CAM

REMARK: Please keep in the AUX interface when switch the CarPlay interface



- 1) Long press and hold "MODE" button to switch MENU, long press "MODE" button again, exit the switch MENU.
- 2) Short press Voice control button to open "Siri".
- 3) Steering wheel controls & Roller to control up/down/right/left/ok.